

Sunline Coach Company  
**Recommended Cleaning Instructions  
for the Exterior of Your New Sunline**

- Aluminum Skin is coated with protective Krystal Koting to prevent minor scratches and dents. Do Not wax. Wash, as you would your car, with soap and water. Clean stubborn spots with Fantastic, mineral spirits or black streak remover.
- Roof: see rubber roof information found in Owner's manual.
- Bumper: Maximum add on weight to rear bumper is 100 lbs.
- Doors, Rock Guard & Luggage Doors: Clean with soap & water then apply a clear liquid wax to help preserve finish.

**CAUTION: DO NOT** walk on your roof without first placing a board across the top over several rafters to evenly distribute your weight.