

Sunline Coach Company
For New Sunline Owners

THINGS TO KEEP IN MIND WHEN USING YOUR NEW SUNLINE TRAILER FOR THE FIRST TIME:

- Remember to install batteries in the smoke detector (9 volt), carbon monoxide detector (3-AAA) and the clock (1-AA).
- Extra light bulbs, 15 amp fuses, 30 amp fuses just in case.
- You will need a lug nut wrench size 13/16 if your car wrench does not fit.
- 12-volt deep cycle marine battery for the 12-volt system and an adapter for the power cord. You will also need to carry heavy-duty extension cords rated for 30 amps and a 30 amp adapter for the power cord. You may also need different lengths of drain hoses depending on campground site hook-ups.
- **Your bumper is rated for 100 lbs.** We recommend that a spare tire with mounting bracket is all that you put on the bumper. For your safety: bike racks are **“NOT”** recommended for mounting on the bumper. A receiver should be welded to the main frame of the unit under the bumper to accommodate bikes. The motion of the bikes (they hang farther out and are higher up) during travel can cause the bumper to weaken and possibly fail. Putting too much weight on the rear of any travel trailer can cause extra sway and compromise the tow-ability of the trailer.
- **Regular** maintenance is needed on all travel trailers. Be sure to tighten water line fittings and p-traps. Vibration from travel may loosen fittings. Be sure to check air pressure on tires before each trip and follow the tire sidewall for recommended air pressure.
- **Things you may want to keep on hand:** roll of putty tape for seals around windows, doors, luggage doors etc. and a tube of self leveling sealant for the roof seals. Seals on roof and around the coach need to be maintained on a regular basis. **BE SURE TO INSPECT THE EXTERIOR SEALS EACH YEAR AND REPAIR AS NEEDED. FAILURE TO DO SO WILL VOID YOUR WARRANTY.**

Customer Assurance
Sunline Coach Co.